



Changing the safe combination Lock

Note: Always keep the safe door open when changing the combination.

S & G New Style

Press 22*

Enter the old combination plus #

Enter the new combination 2 times with the #

Note: A combination is six digits plus the # sign

Old Style

Press Zero 6 Times 000000

Enter the OLD combination

Enter the new combination 2 times

Once the combination is changed, test it 2 to 3 times before closing and locking the door.

Note: All electronic locks use a 9 Volt Battery located either behind the keypad or at the bottom of the keypad. We suggest that you keep several Duracell 9-volt batteries around. Locks that need new batteries will Beep several times warning you of a dying battery.